



This plan is based upon an Ordnance Survey map.
© Crown copyright and database rights 2017 Ordnance Survey
License No. 10018341.

The position of the water mains shown on this plan should not
be relied upon as being precise.
South East Water accept no responsibility in the event of inaccuracy.

For further information about the contents of this plan please contact
South East Water Ltd. This plan (or part) may not be reproduced in any form
without the permission of South East Water Ltd.

South East Water Supply Main		South East Water Abandoned Main	South East Water Company Border	<div><div>×</div><div>AV</div><div>J</div><div>SV</div><div>■</div><div>○</div><div>FH</div><div>WO</div><div>NRV</div><div>PRV</div><div>PSV</div></div> <div>South East Water Main Fittings</div>											
Plot Date:	11/02/2019		Drawing Title: Bassetts Farm												
Grid Reference:	570,617.9104 140,388.3000														
Scale:	1:1,250														
Reference:															

(Water Maps)
PO Box 105
Snodland, Kent
ME6 9DW
Telephone: 0333 000 0059
Email: watermaps@southeastwater.co.uk
Website: www.southeastwater.co.uk